

Flute Care Sheet

Maintaining your flute properly is essential to ensure its longevity and optimal performance. Follow these guidelines to keep your flute in excellent condition:

Cleaning After Each Use

After playing the flute, it is important to clean it each time to prevent moisture from sitting inside and damaging the pads, which can affect the instrument's playability.

Cleaning the Headjoint

1. Remove the headjoint from the flute.
2. Use the provided cleaning cloth and cleaning rod.
3. Wrap the cloth around the rod.
4. Carefully insert the rod into the headjoint to dry the moisture from inside.

Cleaning the Body and Footjoint

1. Separate the body and the footjoint of the flute.
 2. Clean each piece individually using the cleaning rod and cloth.
- Do not attempt to push the cleaning rod and cloth all the way through the body as this can cause it to become stuck and damage the inside of the flute.

Storing the Flute

1. Once cleaned, place each piece of the flute carefully back in the case in its correct spot.
2. Ensure the case is closed properly to protect the instrument.
3. Where possible, store the cleaning cloth and rod in a section of the case that is separate from the flute to avoid any potential damage.

General Storage Tips

1. Always store the flute in its case after each use.
2. Keep the case in a location away from young children who might inadvertently damage the instrument.
3. Avoid leaving the flute lying around after use to prevent accidental damage.

By following these simple steps, you can keep your flute in pristine condition and enjoy its beautiful sound for years to come.